



POS NR	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
4 TAU	●					●			●					●				
6 TAU	●		●			●			●			●		●				
8 TAU	●	●		●		●			●		●		●	●				
10 TAU	●	●		●	●		●	●		●	●		●	●				

HD 265 R90 PLASSERING SPENNTAU